







## **HERCULES +**













Contact your local distributor for installation instructions or detailed specifications.







BO-H+-01



BO-H+-02



BO-H+-03

<sup>\*</sup>Fallzone in shaded region Softfall to AS 4685:1